




Installation Instructions

Mounting plate for

Heating circuit distribution DN 25 / DN 32



Contents

1	General Information.....	3
1.1	Scope of these instructions	3
2	Assembly of the heating circuit on a wall bracket with mounting plate	4
2.1	Assembly of the mounting plate	4
2.2	Assembly of the wall bracket set	6
3	Complete assembly	6

1 General Information




Carefully read these instructions before installation and commissioning. Save these instructions in the vicinity of the installation for future reference.

1.1 Scope of these instructions

These instructions describe the mounting of the mounting plate DN 25 / DN 32 to the heating circuits.

The mounting plate DN 25 can only be mounted to the heating circuit DN 25, The mounting plate DN 32 can only be mounted to the heating circuit DN 32,


2 Assembly of the heating circuit on a wall bracket with mounting plate




2.1 Assembly of the mounting plate

Mount the mounting plate to the heating circuit with a flat sealing screw connection by screwing the union nuts to the external threads of the heating circuit.

Mounting plate DN 25



Mounting plate DN 32



2.2 Assembly of the wall bracket set

The wall bracket set is necessary for the wall assembly. However, it is **not** included in the scope of delivery of the mounting plate and therefore has to be ordered separately (article no. 34722).

3 Complete assembly

Assembly of the heating circuit on a mounting plate with with transition thread connection:





PAW GmbH & Co.KG
Böcklerstr. 11
D-31789 Hameln, Germany

www.paw.eu
Phone: +49 (0) 5151 9856 - 0
Fax: +49 (0) 5151 9856 98